



Test

A/C Switch

Check for continuity between the terminals according to the table.

Terminal No.	①	②	③	④	⑤
Position					
OFF	○	○	○	○	○
ON	○	○	○	○	○

