

# Clutch



## Adjustment

1. Measure the clutch pedal disengagement height.
2. Measure the clutch pedal free play.
3. Adjust the clutch free play by turning the adjusting nut.
4. Make sure that there is 3.0–4.0 mm (0.12–0.16 in.) free play at the tip of release arm after the adjustment.
5. Turn A to right or left to bring the clutch pedal stroke to the specification and tighten nut B.
6. When clutch switch is replaced, install the switch and turn nut B to adjust clearance.

