

Hood

Replacement/Adjustment

1. Pull the windshield washer hose out of the hood.
2. Hold the hood up and remove the 2 hood mounting bolts on each side, then remove the hood.
3. To remove the hood hinges, remove the front windshield wiper and air scoop.
4. When installing the hood, don't tighten the hinge bolts until you've checked the adjustments shown below.

