



Seat Belts

Front Replacement

CAUTION: Check the seat belts for damage (page 14-51), and replace them if necessary. Be careful not to damage them during removal and installation.

1. Remove the quarter trim panel (page 14-44).
2. Remove the upper anchor bolt, lower anchor bolt and retractor bolt with a 17 mm socket or box-end wrench.
3. Slide the front seat forward until the seat belt center anchor bolt is accessible, then remove the bolt and the center anchor.

