

# Ignition System



## Component Location Index

### IGNITION TIMING CONTROL SYSTEM

Troubleshooting, section 5

Inspection and Setting, page 16-47

### IGNITION WIRES

Inspection and Test, page 16-51

### IGNITION TIMING

### ADJUSTING CONNECTOR

### DISTRIBUTOR

Top End Inspection, page 16-48

Removal/Installation, page 16-48 and 49

Overhaul, page 16-50

Reassembly, page 16-51

Ignition coil Test/Replacement,  
page 16-52 and 53

### RADIO NOISE CONDENSER

### SPARK PLUG

Inspection, page 16-54



