

Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



: Apply Power Steering Fluid.



:Apply or check vacuum.

①, ②, ③, : Sequence for removal.
①, ②, ③, : Sequence for removal.

Abbreviation



| | |
|--------|--------------------------------|
| A/C | Air Conditioner |
| BAT | Battery |
| CATA | Catalytic Converter |
| EACV | Electronic Air Control Valve |
| ECU | PGM-FI Electronic Control Unit |
| EX | Exhaust |
| GND | Ground |
| IG | Ignition |
| IN | Intake |
| INT | Intermittent |
| L. | Left Side |
| LHD | Left Hand Drive |
| M/T | Manual Transmission |
| PCV | Positive Crankcase Ventilation |
| PGM-FI | Programmed Fuel-Injection |
| P/S | Power Steering |
| R. | Right Side |
| RHD | Right Hand Drive |
| SW | Switch |
| SOL. V | Solenoid Valve |
| TDC | Top Dead Center |