

Parking Brake

Disassembly and Reassembly

RELEASE BUTTON

PARKING BRAKE LEVER

Check for smooth operation.

PARKING BRAKE SWITCH

Test, Section 16

GREASE
Apply grease to sliding surface.

Check for faulty movement.

CABLE EQUALIZER

CABLE ADJUSTING NUT

22 N·m
(2.2 kg-m, 16 lb-ft)

CLIP
Replace.

PIN

LOCK PIN
Replace.

PARKING BRAKE CABLE

Check for smooth operation.

Disconnect the parking brake cable from the lever on the rear caliper by removing the lock pin and pin.

CLIP
Replace.

PARKING BRAKE CABLE

LOCK PIN
Replace.