

Seats

Rear Disassembly

Disassemble in numbered sequence.

REAR SEAT LATCH

- Remove the clips, then remove the latch cover and carpet. Unscrew the knob and turn over the seat back trim cover, then remove the 2 bolts and seat latch.

