



Troubleshooting

- Any abnormality must be corrected before continuing the test.
- Because of the precise measurements needed, use a voltmeter and ammeter when testing.

Before performing any troubleshooting procedures check:

- Fuses No.15, 18, 32, 38
- All electrical connections are clean and tight.

SYMPTOM	REMEDY
Compressor does not come on.	Perform the procedures in the flow chart. (page 15-30)
Only radiator fan (or condensor fan) does not run.	Perform the procedures in the flow chart. (page 15-33)
Radiator fan and condensor fan do not run.	Perform the procedures in the flow chart. (page 15-34)
Compressor and radiator fan (or condensor fan) do not run.	Perform the procedures in the flow chart. (page 15-37)
	Discharge (high) pressure abnormally high or low.
Idle boost does not work.	See the fuel and emission section.