



### MPFI Wiring diagram for 1991 CRX (HF,SI) (PM8,PM6) (OBD0)

Note the pin outs #'s in this diagram differ from the diagrams you will get from swap forums. But, the colors and positions are the same. You are looking at this as if you are the ECU.

**A**



8	7	6	5		4	3	2	1
17	16	15	14	13	12	11	10	9

**B**



10	9	8	7	6	5	4	3	2	1
20	19	18	17	16	15	14	13	12	11

**C**



28	27	26	25	24	23	22	21
36	35	34	33	32	31	30	29

See:

<http://www.psytronix.org/xo/modules/wfsection/article.php?articleid=5>

**This is the ECU pin out according to swap forums**

**Plug A**

17	15	13	11			7	5	3	1
18	16	14	12	10		8	6	4	2

**Plug B**

19	17	15	13	11	9	7	5	3	1
20	18	16	14	12	10	8	6	4	2

**Plug C**

15	13	11	9	7	5	3	1
16	14	12	10	8	6	4	2