




Drain Tube, Frame, and Frame Seal Replacement

1. Remove the sunroof panel (page 14-36) and the headliner (page 14-45).
2. Disconnect the motor wire harness.
3. Slide back the drain tube clamps and remove the drain tubes.
4. Remove the frame mount bolts, and remove the frame from the car.

NOTE:

- Remove the 2 front bolts last.
- Use added care not to damage the seats or other interior trim.

5. Carefully remove the frame seal.



6. To install, insert the frame's rear hooks into the body holes, then install parts in the reverse order of removal.

NOTE:

- Do not tighten the frame mount bolts before adjusting the side clearance of the sunroof (page 14-34).
- Install the tube clips with the ends facing the side to ease installation of the headliner.