

Troubleshooting

Noise and Vibration

NOTE: Pump noise in first 2—3 minutes after starting in cold weather (-20°C , -4°F or colder) is normal.

