


Lubrication Points


No.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: SE or SF SAE Viscosity: See chart below
2	Transmission Manual	API Service Grade: SE or SF SAE30, 10W-30, 10W-40 or 20W-40 grade oil
3	Brake reservoir	Brake fluid DOT 3
4	Power steering reservoir	Honda power steering fluid P/N 08208-99961
5	Steering gearbox (Power)	Honda steering grease P/N 08740-99969
6	Steering gearbox(Manual)	Multi-purpose Grease
7	Tilt steering	
8	Steering ball joints	
9	Suspension ball joints	
10	Steering boots	
11	Shift lever pivot	
12	Steering column bushings	
13	Pedal linkage	
14	Brake master cylinder push rod	
15	Tailgate hinges	
16	Door hinges upper and lower	
17	Door opening detents	
18	Fuel filler lid	
19	Engine hood hinges	
20	Engine hood latch	
21	Caliper Piston seal Dust seal Caliper pin Piston	Silicone Grease

Recommended Engine Oil
(SE or SF Grade oil)



Engine oil viscosity for ambient temperature ranges.

Recommended Manual Transmission Oil



Transmission oil viscosity for ambient temperature ranges.

