

# Troubleshooting

## Symptom Chart

---

SYMPTOM		REMEDY
No hot air flow	Blower motor does not run	Perform the flowchart (page 15-9)
	Blower motor runs	Check following: <ul style="list-style-type: none"><li>• Clogged heater duct</li><li>• Clogged blower outlet</li><li>• Clogged heater valve</li><li>• Faulty air mix door</li><li>• Air mix cable adjustment</li><li>• Faulty thermostat</li></ul>
Hot air flow is low	Blower speed does not change	Perform flow chart (page 15-11)
	Blower runs properly	Check following: <ul style="list-style-type: none"><li>• Clogged heater duct</li><li>• Clogged blower outlet</li><li>• Incorrect door position</li></ul>
Function does not change	Function control motor does not run	Perform flow chart (page 15-14)
	Function control motor runs	Check for the heater door linkage and cable adjustments.
Recirculation door does not change	Recirculation motor does not run	Perform flow chart (page 15-12)
	Recirculation motor runs	Check for the door linkage or perform flow chart (page 15-17)