


Manual Door Mirror




Removal

1. Remove the knob cap and screw, then remove the control knob.
2. Pry out the cover panel with a flat-tip screwdriver, then remove the cover panel.
3. Remove the mirror mounting screws while holding the mirror.




Mirror Glass Replacement

1. Insert a screwdriver in the mirror through the service hole, and loosen the glass retaining screw.



2. Carefully pry out the mirror with a flat-tip screwdriver as shown.

CAUTION: To prevent damage to the mirror, wrap the end of the screwdriver with a shop towel.



3. Install the mirror in the reverse order of removal, and also apply grease to the location shown.

