


Clutch

Illustrated Index	7-2
Clutch Adjustment	7-3
Release Bearing	7-4
Pressure Plate	7-6
Clutch Disc	7-7
Flywheel	7-8
Flywheel Bearing	7-8
Flywheel and Clutch	7-9



Special Tools

Ref. No	Tool Number	Description	Q'ty	Remarks
①	07924-PD20003	Ring Gear Holder	1	or 07924-PD20002
②	07JAF-PM70100	Clutch Disc Alignment Tool	1	
③	07746-0010100	Attachment 32 x 35 mm	1	
④	07749-0010000	Driver	1	

①

②

③

④

Illustrated Index

NOTE: Whenever the transmission is removed, the release bearing sliding surface should be cleaned and greased (Molybdenum Disulfide).

