




Lighting System

Rear Fog Light Switch Test

- 1. Remove the switch from the instrument panel.
- 2. Check for continuity between the terminals according to the table.

Terminal Position	A	B	C	D	E
ON	○	○	○	○	○
OFF					



Headlights

Adjustment

NOTE: Adjust the headlights to local requirements.

