


Sunroof

Guide Rail Replacement


Roof Guide Rail (on Sunroof panel):

1. Remove the sunroof panel (page 14-36).
2. Remove the nuts and sub-guide rails.




Guide Rail:

1. Remove the frame (page 14-39).
2. Remove 1 bolt and the 3 nuts attaching the guide rail.
3. Remove the sub-guide rail.




4. Pry the guide rail stopper out of the hole of the guide rail; pull out the cable.

NOTE: Remove the guide rail slowly and carefully; it is cemented to the frame.



5. Install the guide rail in the reverse order of removal.

- Check that the slide pin, slider and slide link are reassembled properly when installing the cable to the guide rail.



- Before installing the cable pipes and guide rails on the frame, coat the cable pipe grommets and guide rail attaching surfaces with adhesive (page 14-40).